

The Supervisor is hardwired into the facility LAN and communicates directly with the AGV Supervisor and other pieces of necessary equipment, in the agreed-upon protocol, to transfer materials. The Supervisor relays information and instructions to the CarryMatic Hitch Control and Station Controls.











